

## Step by Step Installation Guide - STRAP ON BOSS (SP319)

1



- \* Cut a 54mm hole into the soil pipe.

2



- \* Solvent weld around the hole and the flange of the Strap on Boss.

3



- \* The Strap on Boss has a built in fall of 2½ degrees.
- \* The word 'top' is embossed on the fitting to show the correct way up.

4



- \* Push fittings together to secure bond.

5



- \* Squeeze the clips at the back together to secure the Strap on Boss to the soil pipe.

6

### FOR PUSH-FIT APPLICATIONS



- \* For Push-Fit connections 32/40/50mm to pipe, use rubber boss adaptors SP10/11/12.

7

### FOR SOLVENT WELD APPLICATIONS



- \* Solvent cement fittings together to secure bond.
- \* For Solvent Weld connections, use solvent weld adaptors SP20/21/22.

For further information,  
please visit our website:

[www.drainagesales.co.uk](http://www.drainagesales.co.uk)